

MAP

KEYS & REMOTES

Programming instructions for KF945

1. On the motor, press and release the 'Programme' button twice quickly.
2. Wait a full 5 seconds.
3. Slowly press the 'Programme' button again (2 second intervals) until you see one or more flashing lights.
4. Once you have one or more flashing lights press and hold the desired button on the new remote. If the new remote was accepted the light/lights will change to solid. Release the button the new remote.
5. Wait 15 seconds before testing.

Note: If the procedure is not successful, turn the motor off at the power point for 10 seconds and restore the power.

Note: If the door starts moving during the procedure, the timing of the 'Programme' button has not been performed correctly. Turn the motor off at the power point and resume from step 1.

Warning! This remote contains a button/coin cell battery. If swallowed, a lithium battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately.

