

MAP

KEYS & REMOTES

Thank you for purchasing a MAP product. Please see below instructions on how to program your replacement garage door remote to your garage door motor.

Part Number: KF920

KF920 Replaces unit pictured below



Determine which garage door motor you have. Each unit has the learn button in a different area. Find the "Learn" button:

1. Overhead / panel motors

- a. If you have five exposed terminal screws at the rear, remove the small black cover to the right of the terminal screws. The 'Learn' button is the red button under the black cover.
- b. If you have four terminal screws at the rear, (possibly covered by a plastic panel) remove the lamp cover, remove the red or green control panel cover, and find the small button marked 'Learn'.
- c. If you have four covered terminal screws at the rear, and a Merlin wired wall switch attached to the motor, the small button on the wall switch is the 'Learn' button.

2. Roller door openers

- a. If you have a single small square red button on the front, remove the lamp cover, and also the small black cover to the left of the lamp holder. 'Learn' is the red button under the black cover.
- b. If you have a large red or green push-switch on the front, remove the red or green panel, and find the small button marked 'Learn'
- c. If you have a large red or green push-switch on the front, and a Merlin wired wall switch attached to the motor, the small button on the wall switch is the 'Learn' button.

3. Other receivers

- a. If you have a dark grey boxed receiver with a large, round, green button, the 'Learn' button is the small dark grey button inside the green button.
- b. If you have a gate receiver card, the 'Learn' button is the tact switch on the PCB marked 'Learn'.
- c. Otherwise, please see your receiver's user guide, or inspect it for a button marked 'Learn'.

Coding your KF920 to the Motor

- a. Press the 'Learn' button for 1-2 seconds,
- b. Press the desired transmitter button twice.

WARNING! This remote contains a button/coin cell battery. If swallowed, a lithium battery can cause severe or fatal injuries within 2 hours or less. Keep batteries out of reach of children at all times whether they are new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or New Zealand National Poisons Centre on 0800 764 766.

