

# **MAP**

## **KEYS & REMOTES**

### **Programming instructions for KF935**

**For 'Superlift' branded motors:**

#### **Roller Doors**

1. Remove the cover from the control box by lifting the tab at the bottom.
2. Press & release the 'Transmitter Coding Button' located next to LED on the recessed circuit board. The LED will illuminate.
3. Press and release the desired button on the new remote. The LED on the control box will extinguish.
4. Replace the cover on the control box.

#### **Sectional/Panel lift Doors:**

1. Located on the back of the motor, press and release the 'Learn' button. The LED will illuminate.
2. Press and release the desired button on the new remote. The LED on the motor will extinguish.

**For 'Avanti' Branded motors:**

1. (If the garage door is open) Close the door.
2. Open the light cover on the motor.
3. Press and release the red 'Learn' button.
4. Press the desired button twice; on the new remote.
5. Replace the light cover

**Warning!** This remote contains a button/coin cell battery. If swallowed, a lithium battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately.

