

# **MAP**

## **KEYS & REMOTES**

***Thank you for purchasing a MAP product. Please see below instructions on how to program your replacement garage door remote to your garage door motor.***

**Part Number: KF900**

**KF900 Replaces unit pictured below**



### **Programming the KF900 to your Sectional/Panel Lift Motor:**

1. Press and hold the button on your KF900 that you want to use to operate the door.
2. Press and release the green/orange 'Learn' button, found on your opener's panel. The opener light will flash once.
3. Now release the KF900 button. If no light bulb is installed, two clicks will be heard.
4. Your KF900 is now programmed to the door. Stand clear & push to test operation.

### **Programming the KF900 to your roller door motor:**

1. Press and hold the button on your KF900 that you want to use to operate the door.
2. Press and release the 'Code Set' button, found on your opener's panel. The opener light will flash once.
3. Now release the KF900 button. If no light bulb is installed, two clicks will be heard.
4. Your KF900 is now programmed to the door. Stand clear & push to test operation.

### **To delete all of the remotes coded to the motor:**

1. Press and hold the "Learn" button on the opener panel until the indicator light turns off (about 6-10 seconds)
2. Press the remote button to test that the transmitter no longer works – all codes, including the courtesy light codes, are now wiped.

**WARNING!** This remote contains a button/coin cell battery. If swallowed, a lithium battery can cause severe or fatal injuries within 2 hours or less. Keep batteries out of reach of children at all times whether they are new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or New Zealand National Poisons Centre on 0800 764 766.

