

# **MAP**

## **KEYS & REMOTES**

***Thank you for purchasing a MAP product. Please see below instructions on how to program your replacement garage door remote to your garage door motor.***

**Part Number: KF901**

**KF901 Replaces unit pictured below**



### **Programming the KF901 to your motor:**

1. Press the code set button on your motor and release – the LED for the Code Set button should illuminate indicating that the opener is in learn mode. If a valid code isn't stored within 15 seconds, the opener will automatically drop out of learn mode.
2. Press the button on the KF901 you would like to use to control the door. The LED will flash.
3. Press the same button on the KF901 again. The LED will illuminate for a full second, and then go out.
4. Press the chosen button on the KF901 to test the operation of the opener.

### **To program remote 'Light' function:**

1. Press the code set button twice & then follow steps 1-4 (above) using another button on your new remote.

### **Default coding type is ATA TrioCode:**

Press and hold Key1 and Key2 of remote control at the same time, LED turns on, after 4 seconds, LED turns off, release the buttons, the coding type has been switched successfully.

### **To delete all of the remotes coded to the motor:**

1. Press the code set button on the motor, hold it for 6 seconds. The code set LED will blink rapidly for one second to indicate all programmed codes have been erased.  
Press the transmitter button to test the operation of the opener

**WARNING!** This remote contains a button/coin cell battery. If swallowed, a lithium battery can cause severe or fatal injuries within 2 hours or less. Keep batteries out of reach of children at all times whether they are new or used. If you think batteries may have been swallowed or placed inside any part of the body, seek medical attention immediately or contact the Australian Poisons Information Centre on 13 11 26 or New Zealand National Poisons Centre on 0800 764 766.

